

## Sewing Machine Needle Chart

Which Needle System Do I Need for my Machine?

MAKE	MODEL #	NEEDLE
Adler	67	135 x 5 (134)
Adler	98-2	134-35R
Adler	166	328R
Adler	167	135 x 5 (134)
Artisan	618-1SC / SC LTHR	135 x 17, 135 x 16 DI
Artisan	797AB-800 / AB / ABN	135 x 17, 135 x 16 DI
Artisan	797 AB LTHR / ABNS LTHR	135 x 17, 135 x 16 DI
Artisan	4420 / 4420-25	135 x 17, 135 x 16 DI
Artisan	4420 / 440-25 / LTHR	135 x 17, 135 x 16 DI
Artisan	518	135 x 5 (134)
Artisan	2220M / B	135 x 5 (134)
Artisan	2240M / B	135 x 5 (134)
Artisan	TORO 2600	328R
Artisan	TORO 2500-132	328R
Bernina	217	16 x 95 (287WKH)
Brother	TZB 652 / 651	16 x 95 (16 x 231)
Brother	714 / 735 / 755	16 x 95 (16 x 231)
Consew	272	135 x 5 (134)
Consew	206RB	135 x 17, 135 x 16 DI
Consew	225 / 226	135 x 17, 135 x 16 DI
Consew	99	16 x 95
Consew	199RI / R3	16 x 95
Consew	146RB	135 x 17, 135 x 16 DI
Consew	255RB	135 x 17, 135 x 16 DI
Juki	LU56Z	135 x 17, 135 x 16 DI
Juki	LH512	135 x 5 (134)
Juki	LU561	135 x 17, 135 x 16 DI
Juki	DDL-5530	16 x 95 (16 x 231)
Juki	DDL-227	16 x 95 (16 x 231)
Phaff	138, 238	135 x 5 (134)

MAKE	MODEL #	NEEDLE
Phaff	145	135 x 5 (134)
Phaff	545	135 x 5 (134)
Reeds	Sailmaker	System 130
Sailrite	111	135 x 17, 135 x 16 DI
Sailrite	Apprentice	System 130
Sailrite	Big-N-Tall	135 x 17, 135 x 16 DI
Sailrite	Fabricator	135 x 17, 135 x 16 DI
Sailrite	Professional	UY 128 GAS
Sailrite	Sailmaker	16 x 95
Sailrite	SR200 / Long Arm	135 x 5 (134)
Sailrite	Ultrafeed	135 x 17, 135 x 16 DI
Sailrite	Yachtsman	System 130
Singer	107	135 x 5 (134)
Singer	111-W100	135 x 5 (134)
Singer	111-W112	135 x 17, 135 x 16 DI
Singer	111-W151 / W153	135 x 17, 135 x 16 DI
Singer	167	135 x 5 (134)
Singer	31-15	16 x 87
Singer	20U	135 x 5 (1955)
Tacsew	111 - 115	135 x 17, 135 x 16 DI
Thompson	Mini Walker	135 x 17, 135 x 16 DI



**Sailrite Enterprises, Inc.**

2390 East 100 South, Columbia City, IN 46725

**Phone** (800) 348-2769 / (260) 244-4647

**Fax** (260) 818-2005

**Email** info@sailrite.com

**Sailrite.com**

© 2017 Sailrite Enterprises, Inc.